

EYELETS TOOLS



Die Sets For Eyelets


- T-1225** (2 pc. set) Sets A-257 Eyelets
- T-1226** (2 pc. set) Sets A-258, A-275 A-329 Eyelets
- T-1227** (2 pc. set) Sets A-259 Eyelets
- T-1228** (2 pc. set) Sets A-260 Eyelets



These die sets can be used for production work in the following machines: T-1131, T-1133, T-1490 (see page 22). For more limited work use the T-1233 Bottom Die Holder and T-1232 Top Die Holder pictured on the previous page.



T-456 Hand tool. Eyelet setter spreads eyelets so that they can be flattened with a hammer. Knurled handle prevents slipping. Chrome plated. Will not rust or tarnish. Sets many Popular Sizes. Very economical price.



A-348 A-258 A-275 A-343



A-344 A-345 A-259

see page 11 for colors.



T-256 Eyelet Remover Tool
This tool will remove eyelets which already have been set. Great repair tool!

EYELET HAND SETTING TOOLS

Eyelet Setter Pliers.

T-1616

1/4" Pliers fit: A-348, A-258, A-275 and A-343 eyelets.

T-1617

5/32" Pliers fit: A-344, A-345, A-259 eyelets.



NEW T-1616 or T-1617

NEW



Grommet Dies with Hole Cutter
Sold by the set.

- T-1611-00** Fits size 00 grommets (3/16")
- T-1611-0** Fits size 0 grommets (1/4")
- T-1611-1** Fits size 1 grommets (9/32")
- T-1611-2** Fits size 2 grommets (3/8")
- T-1611-3** Fits size 3 grommets (7/16")
- T-1611-4** Fits size 4 grommets (1/2")
- T-1611-5** Fits size 5 grommets (5/8")

NOTE: Cutting block included with machine is used with hole cutter.

T-1612 Hand Machine

For setting snaps, grommets and rivets. Easily bolts to table and is very portable. Made from heavy cast iron! Includes cutting block.




T-1608 Rivet Die Set

Set includes 4 dies, two top and two bottom dies.

Fits:

- Jiffy Rivets: Double and Single caps baby, small and medium sizes. 206, 307, 309, 311, 407, 409, A-313, A-339, A-340, A-337.
- Tubular Rivets: 1969, HM and 252 with the #40 or HM rivet caps.



T-1609 Regular Snap Die Set

Set includes 4 dies for setting ligne 24 snaps.

T-1610 Baby Snap Die Set

Set includes 3 dies for setting ligne 20 snaps.